

# Lenovo 100e/300e Windows 2nd Gen User Guide



Lenovo



**IMPORTANT**

Use your FULL  
FPS email address  
as your Username  
to login BEFORE  
you leave school!





## HOW TO CARE FOR YOUR DEVICE



**CLEAN YOUR DEVICE WITH  
APPROVED PRODUCTS**



**DO NOT ATTEMPT TO REPAIR  
YOUR OWN DEVICE, LET A  
TEACHER KNOW**



**CARRY DEVICE IN A PROPER  
BAG OR CASE**



**DO NOT LEAVE IN EXTREME  
TEMPERATURES**



**DO NOT CARRY DEVICE BY  
SCREEN, CLOSE WHEN  
CARRYING**



**DO NOT PLACE HEAVY  
OBJECTS ON TOP OF DEVICE**



**FOOD AND DRINKS ARE NOT  
ALLOWED AROUND THE  
DEVICE**

# DEVICE GUIDELINES FOR TEACHERS/STAFF



**IF STUDENTS DEVICE NEEDS  
REPAIR, CONTACT IT AND  
PLACE A HELPDESK TICKET  
ONLINE**

508-543-1555 or EXT 50100

**IF FULLY REMOTE, THERE  
WILL DESIGNATED DROP-OFF  
AREAS FOR REPAIRS**

There will be a location at every  
school building..



**REVIEW GUIDLINES OF DEVICE  
CARE WITH STUDENTS**

Ensure that students understand  
what they can and cannot do with  
their devices.

**ASSIST STUDENTS WITH  
LOGGING ON FOR FIRST TIME**




Show where the programs are  
that will be using for the class.



Need an application that's not already downloaded?  
Go to start menu to navigate to...


Company Portal – replaces the “Software Center”  
for FPS specific apps (e.g. eBeam software, HoverCam software, etc)

Microsoft Store – see “Foxborough Public Schools” tab for pre-approved apps





Work in the cloud for easy transition between devices




Network Drives are unavailable



Do NOT connect your laptop to classroom projectors! Continue to use your classroom teacher computer

# Meet your computer



---

Take pictures or record videos by clicking **Camera** from the Start menu. The indicator next to the camera is on when the camera is in use.

## 1. Front camera

If you use other apps that support photographing, video chatting, and video conference, the camera starts automatically when you enable the camera-required feature from the app.

---

## 2. Microphone


Captures or records sound and voice.

---

## 3. Screen

Displays text, graphics, and videos.


## Left




1. Battery/Charging status indicator	This indicator shows whether the ac power is connected to the computer and the battery power status of the computer.
2. USB-C™ connector / Power connector	<ul style="list-style-type: none"><li>Charges your computer.</li></ul>
3. Always On USB 3.0 connector	To charge the USB-compatible devices when your computer is off, in sleep mode, or in hibernation mode, enable the Always On USB feature on your computer. See “Enable/ Disable always-on” on page 30.
4. HDMI™ connector	Connect to a compatible digital audio device or video monitor, such as an HDTV.
5. Audio connector	Connect headphones or a headset with a 3.5-mm (0.14-inch) and 4-pole plug to listen to the sound from the computer. <b>Note:</b> The audio connector does not support conventional microphones.



# Right




1. Pen slot*	Selected models are equipped with Lenovo Integrated Pen. Use the pen slot to store Lenovo Integrated Pen.
2. Volume up/down button*	Increase/decrease the volume level.
3. Power button	Press to turn on the computer or put the computer to sleep mode.  To turn off the computer, open the Start menu, click  <b>Power</b> , and then click <b>Shut down</b> .
4. USB 3.0 connector	Connect to USB-compatible devices, such as a USB keyboard, USB mouse, USB storage device, or USB printer.
5. MicroSD card slot	Insert a microSD card for data access or storage.
6. Mini security-lock slot	Lock your computer to a desk, table, or other fixtures through a compatible security cable lock.

# Use the multi-touch screen

The screen of Lenovo 300e Windows 2nd Gen supports the multi-touch function. You can navigate the screen with simple touch gestures.

**Note:** Some gestures might not be available depending on the app you use.




## Tap once

- From the Start menu: Open an app or item.
- From the desktop: Select an app or item.
- In an open app: Perform an action such as **Copy**, **Save**, and **Delete**, depending on the app.




## Tap twice quickly

Open an app or item from the desktop.



## Tap and hold

Open a shortcut menu.

















## Slide

Scroll through items, such as lists, pages, and photos.

# Hotkeys

Some keys on the keyboard are printed with icons. These keys are called hotkeys and can be pressed alone or in combination with the Fn key to access certain Windows functions or settings quickly. The functions of hotkeys are symbolized by the icons printed on them.


Hotkey	Function
	Mutes/Unmutes the computer.  If you mute the computer and turn off your computer, the speakers remain muted when you turn on your computer.
 - / 	Decreases/Increases volume.
	Enables/Disables the microphones.
	Refreshes the current window.
	Enables/Disables the touchpad.
	Turns on/off airplane mode.
	Enables/Disables the camera.
	Locks the current user account.
 	Manages external displays.
 - / 	Decreases/Increases display brightness.
<b>Fn</b> + 	Equal the Home key.




IT does not have  
extra chargers  
available.  
Replacement  
chargers are \$50.




**Notebook mode**



**Stand mode**



**Tent mode**



**Tablet mode**